



550 Highland Street Ste. 420, Frederick, MD 21701 | 800-806-7997 | 240-575-5852 | F 301-620-7868

Premiere 78" with Large Scroll and Finial Installation Instructions:

Required Materials:

- Digging Iron
- Post Hole Digger
- Allen wrench or Hex key & screwdriver for tightening
- 60# bag of quickcrete
- Leveling tool to adjust and make sure post is straight
- (8) 1 ¼" Drywall Screws

Suggested Instruction:

1. Dig Hole so mailbox door is 6-8 inches from curb
2. Hole should be deep enough so that your mailbox sits 41-45 inches above surface
3. Hole should be 8-10 inches in diameter so there is ample room for quickcrete to settle
4. Place post in hole and level then add dry quickcrete (approx ½ bag)
5. Once post is level tamp dry quickcrete around post then add soil on top of crete & around post
6. Once post is set and level slide base over post and tighten allen screws with allen wrench
7. Then add and screw on large scroll to post
8. Place finial on top of post and tighten allen screws with allen wrench
9. Next add mailbox on top of mortar board or newsbin (if ordered) and attached using 1 ¼" drywall screws supplied
10. Allow system to set up for 2 days ... quickcrete absorbs ground moisture

Thank you for your purchase and if you have any questions or need assistance with installation please contact us at 301-620-7585.